




SMART | ACTIVE | MUSIC

# Owners Manual

**((AE))**  
ACOUSTIC ENERGY

# Setting up your AegoM



# Specification

Active sub / sat system with patented advanced technology satellite driver featuring a unique heat transfer system; special high excursion suspension and a computer-designed anti-resonant cone.

- INPUTS:** 3 x RCA Phono—Line Level  
1 x Stereo Mini jack—Line level
- OUTPUTS:** 3 x Speaker terminals
- CONTROLS:** 1 x Volume/Power pot  
1 x Bass switch (3 position)
- ACCESSORIES:** 2 x 5 metre Speaker cables  
1 x 2 metre Signal input cable  
1 x 2 metre Mini jack input cable  
1 x Speaker level to line level adaptor cable
- POWER RATINGS:** 240v Model—220/240v @ 50/60Hz; 80VA
- DIMENSIONS:** Sub Woofer—265x190x350 mm  
Satellites—88x103x90 mm
- WEIGHT:** 9 Kg
- FINISHES:** Black sub woofer  
Textured black satellites with black grilles  
White subwoofer  
Textured white satellites with black grilles

# Warranty

Your Acoustic Energy loudspeakers are guaranteed against original defects in materials, manufacture and workmanship for 1 year from the date of purchase. Please retain all original packaging materials for possible future use.

Under this warranty Acoustic Energy agrees to repair any defect or, at the company's discretion, replace the faulty component(s) without charge for parts and labour. This warranty does not imply any acceptance by Acoustic Energy or its agents for consequential loss or damage and specifically excludes fair wear and tear, accident, misuse or unauthorised modification.

This warranty is applicable in the United Kingdom only and does not in any way limit the customer's legal rights. Claims and enquiries under the warranty for AE products purchased outside the UK should be addressed to the local importers or distributors.

**If you have reason to claim under the warranty please contact your dealer in the first instance.**

# WARNING

To reduce the risk of fire or electric shock, do not expose this system to rain or moisture

To reduce the risk of shock, do not remove the cover of this system. There are no user-serviceable parts inside. Refer servicing to qualified service personnel.

The lightning flash, with arrowhead symbol within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the system enclosure that may be of sufficient magnitude to constitute a risk of electrical shock.

The exclamation point within an equilateral triangle as marked on the system is intended to alert the user to the presence of important operating and maintenance instructions in this owner's guide



Acoustic Energy Ltd 16 Bridge Road Cirencester Glos

Tel: +44 (0) 1285 654432

Fax: +44 (0) 1285 654430

Technical Help +44 (0) 1285 656890

E-mail: [info@acoustic-energy.co.uk](mailto:info@acoustic-energy.co.uk)

DESIGNED BY ACOUSTIC ENERGY LTD (UK)

MANUFACTURED IN MALAYSIA